










Table of Signal Cable

Item	Compatible Detectors	Cable	Model Name/Specifications
1	MP- 610•610B•9100•9120• 9200•940A•963 MP- 810B•820B•830B (MP-081+MX-005 Series)	3C-2V (high-frequency coaxial cable)	MX-005 5 m 010 10 m 015 15 m 020 20 m 
2	MP- 930•935•936•950•962 FG-1200	3C-2V (high-frequency coaxial cable)	MX-101 1.5 m 105 5 m 110 10 m 115 15 m 120 20 m 
3	MX- 000 Series cable 100 Series cable	P-2 (2-core outer shielded cable)	MX-603 0.3 m 
4	MP- 610•610B•9100•9120• 9200•940A•963 MP- 810B•820B•830B (MP-081+MX-500 Series)	P-2 (2-core outer shielded cable)	MX-505 5 m 510 10 m 520 20 m 
5	MP- 981 LG- 916	D-5 (Composite 5-core vinyl sheath cable)	MX-705 5 m 710 10 m 715 15 m 720 20 m MX-705: One end is open. MX-710 and longer: One end is fitted with crimp terminals.  *The MX-705 uses the R03-PB6F connector.
6	MP- 981 LG- 916	D-5 (Composite 5-core vinyl sheath cable)	MX-805A 5 m 810 10 m 815 15 m 820 20 m  *The MX-805A uses the R03-PB6F connector.
7	RP- 721	R-6 (twisted-pair cable)	RP- 004 5 m *10 m 
8	RP- 721•732	R-6 (twisted-pair cable)	RP- 006 5 m *10 m 
9	RP- 432Z	R-8 (twisted-pair cable)	RP- 008 5 m *10 m 

* Manufactured after receipt of order

- When several counters are connected to one detector, you will find it convenient to use BNC-JPJ connector.

