




The SP2 String Pot from Celesco is a compact, economical and water resistant device that utilizes a flexible cable, a spring-loaded spool and a potentiometer to detect and measure linear position.

The SP2 is identical to the SP1 except for an added 40-inch electrical cable with a watertight rubber strain relief. The SP2 has been compactly designed for tight spaces and high cycle applications and generously allows for measuring cable misalignment. With 4 different ranges and a handy mounting bracket, the SP2 is a perfect solution for many applications from light industrial to OEM.

Output Signal



SP2

Compact String Pot • Incremental

Linear Position to 50 inches (1270 mm)

Low-Cost, Long Life • Rugged Polycarbonate Enclosure
40-in. Electrical Cable • Free-Release Tolerant
In Stock for Quick Delivery!

Specifications

Full Stroke Range0-4.75, 0-12.5, 0-25, 0-50 inchesOptions Output Signalvoltage divider (potentiometer)Accuracy ± 0.25 to $\pm 1.00\%$ (see part no. above)

Repeatability $\pm 0.05\%$ full stroke **Resolution** essentially infinite

Measuring Cable 0.019-in. dia. nylon-coated stainless

Measuring Cable Tension steel 7 oz. (1,9 N) ±25%

Maximum Cable Acceleration 15 g

Enclosure polycarbonate

Material Sensor plastic-hybrid precision

Weight potentiometer 5 oz. (w/o mounting

bracket) max.

10K ohms, ±10%

Electrical

Power Rating, Watts 2.0 at 70°F derated to 0 at

Recommended 250° 30 V (AC/DC)

Maximum Input Voltage

Input Resistance

Output Signal Change 94% ±4% of input voltage

Over Full Stroke Range


Electrical Connection 40-inch long, 24 gauge shielded electrical cable

Environmental

Enclosure IP 50

Operating 0° to 160°F (-18° to 71°C)

Temperature Vibration up to 10 g to 2000 Hz maximum




Part No.	full stroke range	(% of f.s.)	cycle life
SP2-4	4.75 in (120 mm)	1.00%	2.5M cycles
SP2-12	12.5 in (317 mm)	0.25%	500K cycles
SP2-25	25 in (635 mm)	0.25%	500K cycles
SP2-50	50 in (1270 mm)	0.25%	250K cycles

full stucks

Mounting Options Electrical Connection For added flexibilty, mounting bracket +in (red) can easily be switched to the opposite side. +out common (green) (black) To change measuring cable direction simply remove the 3 bracket attaching screws 2.50 [63,5] -.57 [14,5] 2.50 [63,5] and rotate sensor body to desired direction. 1.63 [41,4] .48 [12,2] 1.45 [36,8]

Outline Drawing (w/o bracket)




DIMENSIONS ARE IN INCHES [MM] tolerances are 0.04 IN. [1,0 MM] unless otherwise noted.


SENSOR SOLUTIONS /// SP2 12//2015 Page 2

^{*} tolerance = +.005 -.001 [+0,1 -0,0]


^{**} tolerance = +.005 -.005 [+0,1 -0,1]


Outline Drawing (w/ bracket)





DIMENSIONS ARE IN INCHES [MM] tolerances are 0.04 IN. [1,0 MM] unless otherwise noted.





- * tolerance = +.005 -.001 [+0,1 -0,0]
- ** tolerance = +.005 -.005 [+0,1 -0,1]

TE.com/sensorsolutions

Measurement Specialties, Inc., a TE Connectivity company.

Measurement Specialties, TE Connectivity, TE Connectivity (logo) and EVERY CONNECTION COUNTS are trademarks. All other logos, products and/or company names referred to herein might be trademarks of their respective owners.

The information given herein, including drawings, illustrations and schematics which are intended for illustration purposes only, is believed to be reliable. However, TE Connectivity makes no warranties as to its accuracy or completeness and disclaims any liability in connection with its use. TE Connectivity's obligations shall only be as set forth in TE Connectivity's Standard Terms and Conditions of Sale for this product and in no case will TE Connectivity be liable for any incidental, indirect or consequential damages arising out of the sale, resale, use or misuse of the product. Users of TE Connectivity products should make their own evaluation to determine the suitability of each such product for the specific application.

© 2015 TE Connectivity Ltd. family of companies All Rights Reserved.

SP2 12/01/2015

SENSOR SOLUTIONS /// SP2 12//2015 Page 3